

brume stickers

fitting Instructions

1. Make sure the surface you are applying the stickers to is flat, clean and grease free. If applying to newly painted surfaces wait at least 14 -21 days before application.
2. If you have a collection of stickers on a backing sheet, cut around each one with a generous margin. N.B. Do not do this if you have wording as the stickers will be spaced perfectly.
3. If you require the sticker to be perfectly horizontal, (for instance if you have wording) mark a positioning line on the surface with masking tape.
4. Take each sticker and lay it out on a hard surface with the stiff white backing face up. Give the backing a firm rub down with an old credit card.
5. Carefully remove the stiff white backing. The sticker should remain in tact on the soft sticky application tape. If the sticker does not stay on the tape, rub over the stiff backing again.
6. Position the sticker on your chosen surface and hold in place with masking tape.
7. Rub over the application tape with an old credit card using firm strokes and smooth the sticker onto the surface. Start at the top and work down and out to each edge. Then carefully peel away the application tape.

WARNING – Do not apply stickers within reach of children under 3 years old.