

brume window sticker

text & numbers- fitting instructions

Please read the instructions before fitting your window sticker.

Tools you will need:

A window scraper

Credit Card

Spray bottle containing detergent solution (3-4 drops of fairy liquid added to 500ml water)

1. Wash your window and make sure the glass is free of grit and fluff. Remove any surface debris with the window scraper.
2. Around your sticker there is a positioning frame made from the same material as your text/number. It will either be the same dimension as your window or be slightly larger than your individual number/text. This will help guide the location of your sticker and will be removed after installation.
3. If the frame is the same size as your window, go to step 4. If the frame is slightly bigger than your text you will need to mark the glass with masking tape to show where this frame should sit.
4. Take your sticker and lay it out on a hard surface the stiff white backing face up. Give the backing a firm rub down with an old credit card.
5. Then carefully remove the stiff white backing. The sticker should remain in tact on the soft sticky application tape. If the sticker does not stay on the tape rub over the stiff backing again and try again.
6. Spray the sticky surface of the sticker with the detergent solution.
7. Position the application tape and sticker on the window with a piece of masking tape in each top corner.
8. Starting at the top, rub over the soft sticky application tape with the credit card with firm strokes and smooth the sticker to the window. Start at the top and work down and out to each edge.
9. Wait until dry (this may take 1-4 hours). Then starting at the top carefully peel away the soft application tape. If the sticker lifts off with the application tape simply rub it back down again and try again. Finally remove the positioning frame.